OWNER'S MANUAL / SAFETY INSTRUCTIONS / COMPLIANCE INFORMATION



DSB-150

Bluetooth® Wireless Speaker System

Français

Système de haut-parleurs sans fil Bluetooth®

MANUEL DE L'UTILISATEUR / INSTRUCTIONS DE SÉCURITÉ / INFORMATIONS SUR LA CONFORMITÉ

Español

Sistema de altavoces inalámbricos por Bluetooth®

MANUAL DEL PROPIETARIO/INSTRUCCIONES DE SEGURIDAD /INFORMACIÓN DE CUMPLIMIENTO

DENON®

FCC / IC Information

❑ FCC Information (For US customers)

1. IMPORTANT NOTICE:DO NOT MODIFY THIS PRODUCT

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modification not expressly approved by Denon may void your authority, granted by the FCC, to use the product.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2. CAUTION

- To comply with FCC RF exposure compliance requirement, separation distance of at least 20 cm must be maintained between this product and all persons.
- This product and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

3. COMPLIANCE INFORMATION

- **Product Name : Bluetooth® Wireless Speaker System**
- **Model Number : DSB-150**
- **FCC ID : XN6 - DSB150**

This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this product may not cause harmful interference, and (2) this product must accept any interference received, including interference that may cause undesired operation.
Denon Electronics (USA), LLC
(a D&M Holdings Company)
100 Corporate Drive
Mahwah, NJ 07430-2041
Tel. (201) 762-6665

4. NOTE

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the local retailer authorized to distribute this type of product or an experienced radio/TV technician for help.

❑ IC Information (For Canadian customers)

1. PRODUCT
IC No: 8819A - DSB150

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this product may not cause harmful interference, and (2) this product must accept any interference received, including interference that may cause undesired operation. This Class B digital apparatus complies with Canadian ICES-003.

2. CAUTION

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.

❑ Informations sur IC (pour les clients canadiens)

1. APPAREIL
IC No: 8819A - DSB150

Cet appareil est conforme aux normes d'Industrie du Canada applicables aux appareils exempts de licence RSS. L'utilisation de ce dispositif est autorisée seulement aux deux conditions suivantes : (1) il ne doit pas produire de brouillage, et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

2. ATTENTION

Afin de réduire le risque d'interférence aux autres utilisateurs, il faut choisir le type d'antenne et son gain de façon à ce que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne soit pas supérieure au niveau requis pour l'obtention d'une communication satisfaisante.

For Canadian customers:
CAN ICES-3 (B)/NMB-3 (B)

❑ RF Exposure Information

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption ratio (SAR).
Cet équipement est conforme aux normes d'exposition aux radiations FCC/IC définies pour un environnement non contrôlé et satisfait les directives d'exposition à la radiofréquence (RF) dans le supplément C des OET65 et RSS-102 des règles d'exposition à la fréquence radio (RF) IC. Cet équipement a de très faibles niveaux d'énergie RF qui sont jugés conformes sans test de taux d'absorption spécifique (SAR).

Read these safety instructions before operating the unit.

❑ SAFETY PRECAUTIONS

CAUTION:
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings.
   Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the AC adapter from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

WARNING : DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD

- The remote control supplied with this product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have swallowed or placed inside any part of the body, seek immediate Medical attention.
- Do not keep the battery in a place exposed to direct sunlight or in places with extremely high temperatures, such as near a heater.
- Used batteries should be disposed of in accordance with the local regulations regarding battery disposal.

WARNINGS

❑ NOTES ON USE

- Avoid high temperatures.
- Allow for sufficient heat dispersion when installed in a rack.
- Keep the unit free from moisture, water, and dust.
- Unplug the AC adapter when not using the unit for long periods of time.
- Do not let insecticides, benzene, and thinner come in contact with the unit.
- Never disassemble or modify the unit in any way.
- Naked flame sources such as lighted candles should not be placed on the unit.
- The apparatus shall not be exposed to dripping or splashing. No objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not handle the AC adapter with wet hands.
- When the switch is in the OFF (STANDBY) position, the equipment is not completely switched off from MAINS.
- The equipment shall be installed near the power supply so that the power supply is easily accessible.

CAUTION:
To completely disconnect this product from the mains, disconnect the plug from the wall socket outlet. The mains plug is used to completely interrupt the power supply to the unit and must be within easy access by the user.

Introduction

Thank you for choosing DENON® and congratulations on your purchase of the DSB-150 wireless speaker system. The DSB-150 is a self-amplified stereo speaker system that uses Bluetooth® wireless communication to receive a signal from any standard Bluetooth equipped device capable of stereo audio transmission (A2DP).

Using the simple controls on the DSB-150, and its remote control, you can adjust the volume of the system or operate the basic music play back functions of your connected devices. An auxiliary analog input also allows you to connect any music source that has a standard 3.5mm connector to the DSB-150. We hope you'll enjoy it for years to come.

Features

- Outstanding stereo performance from dual high-performance Denon-designed 3½ inch speakers in separate acoustic chambers, vented for extended bass response
- Bluetooth wireless streaming from any compatible Bluetooth music player, phone, tablet or computer
- Tap-to-pair functionality for instant connection with any device that supports Near Field Communication (NFC)
- AptX codec for CD-like sound quality over Bluetooth
- Auxiliary input
- Easy-to-use controls
- Volume level display behind grille
- Remote control with music playback controls
- Headphone output
- Elegant styling with beautiful high-gloss finish

Unpacking and Setting Up Your DSB-150

Carefully unpack the system. If there is any sign of damage from transit, report it immediately to your dealer and/or delivery service. Keep the shipping carton and packing materials for future use. Be sure to keep your purchase receipt in a safe place, as it may be required for warranty purposes.



In the carton you should find the DSB-150, remote control, power supply and a power plug adapter

Placement

Your DSB-150 will sound great just about anywhere. If you put it near a wall or corner the bass response will be enhanced. Blocking the bass ports on the rear of the cabinet will reduce bass response.

Power Connection
Attach the power plug adapter plate to the power supply. Plug the power supply into the wall power outlet. Connect the other cable from the power supply to the power input on the back of the unit.

Service Connector
The service port is used for software updates only.

Reset Button
Returns the DSB-150 settings to the defaults values.



Controls

power – There are three power states.

- **on** - the button is lit blue. The system is powered up.
- **standby** – button is lit red. The system is powered down, but will automatically turn on when a new audio signal appears from a connected device.
- **off** – button is not lit. The system is powered down completely and will not respond to audio signals.



A quick press of the button will toggle between on and standby states. Press and hold the button to turn the system off.

Bluetooth input – Press to select the Bluetooth wireless input. The button blinks rapidly when pairing and stays lit when the system is connected to a Bluetooth device. See the "Bluetooth Details" section of this manual for more information.

auxiliary input – press to select the auxiliary input. The top button lights when the auxiliary input is selected.

muting – to mute the sound or restore it to the previous volume level. When the sound is muted, the button is lit.

volume down – press to reduce volume.

volume up – press to increase volume.

Volume Display

There is a 10-segment volume display on the front behind the grille. The display lights blue when volume adjustments are made. After a few seconds the display turns off. When the system receives a signal from the remote control, the bottom LED flickers.



Remote Control

The remote control has the same buttons as are on the top of the system, with the addition of playback control buttons that let you control your compatible Bluetooth devices:



- ►II Play /Pause
- ■ Stop
- I◄◄ Skip back / fast reverse
- ►►I Skip forward / fast forward

Notes About the Remote

When you unpack your remote control there will be a plastic tab extending from the battery compartment. This keeps the battery from being depleted. Pull out this tab before using the remote control. Eventually you'll need to replace the remote battery. When the battery is depleted, the remote won't reliably operate the DSB-150. You will need to replace it with a new CR2025 3V lithium coin-type battery, available at many retailers.

When using the remote you should be able to see the DSB-150. Point the remote control at the front panel of the system when pressing the buttons. If the DSB-150 does not respond to the remote, try moving closer to the system. Operating range is specified to be 15 feet, ±30°.

Bluetooth Details

Getting Started – Pairing

Before you can stream Bluetooth audio to your DSB-150, you have to pair it to your device.

To pair the DSB-150 to a device for the first time:

1. Go to Bluetooth settings on your device. Make sure the device's Bluetooth feature is set to "on".

2. Turn on the DSB-150 by pressing the ⏻ button. The button will light solid blue. The ᛒ button will begin to flash, indicating that the system is searching for a device with which to pair.



3. The DSB-150 has two ways to initiate pairing:

NFC (Near Field Communication) or "tap-to-pair". The newest and easiest pairing method. If you have an NFC enabled device, simply place it gently on the top of the DSB-150. Your phone or tablet does the rest, and you can be playing audio within seconds.

Press and hold the ᛒ button on the top of the DSB-150, or on the remote, for 3 seconds. The ᛒ button on the top will begin to flash blue, indicating that the system is looking for your device.



Look at the Bluetooth list on your device. You may have to select "search for devices" for a new device to appear in the list of available devices. Once "DSB-150" appears in that list, simply select to pair.

When the ᛒ button on top lights solid blue, you are ready to go! Fire up your music and enjoy!

Once the DSB-150 is paired to a device, its Bluetooth address is stored in a 'Paired List' so it can hook up to that device easily in the future. The DSB-150 is capable of storing up to 8 different devices. Once that limit is exceeded, the oldest device is cleared so that a new one can be stored.

After the first pairing, the DSB-150 will automatically connect to your device when it is in range. The ᛒ button on top of the DSB-150 will light solid blue to indicate the system is ready to stream music from your connected device. If a song is already playing through the device, the DSB-150 will start playing.

Note: If the Bluetooth button is lit, but nothing is heard:

1. Check the device to make sure a selection is playing. Make sure your music is not paused.
2. Check the device and the DSB-150 to make sure their volume levels are up and MUTE is not enabled on either of them.

The DSB-150 will stay in pairing mode for up to 5 minutes, searching for a Bluetooth device (which must also be in pairing mode). If it does not find a device, the Bluetooth button will light red to indicate that it was not able to pair. To try pairing again, press and release the **RESET** button on the back of the DSB-150. The ᛒ button will begin to flash, indicating that the system is searching for a device with which to pair. If you are still having trouble, try moving the device closer to the DSB-150 and repeat the pairing process.

Connecting Headphones

Connect the headphone plug to the 3.5mm jack beside the 🎧 symbol. This turns off the DSB-150 internal speakers. If your headphones have a larger 1/4-inch plug you will need an adapter, available at many retailers.

Auxiliary Input



Press the **AUX** button on the top or on the remote control. The **AUX** button on the top will light blue.

The DSB-150 can accept an analog signal from a wide range of sources—from CD players to MP3 players, and even older legacy devices. You'll need a cable with a standard 3.5mm stereo mini plug to connect between the source and the auxiliary input on the left side of the system.

Note: The analog output signals from some sources can be fairly strong. If the volume level of the source device is turned up too high, it could overload the inputs of the DSB-150. This is unlikely to cause damage, but can cause distorted sound. Initially, set the volume of the source to a medium – low level, then turn it up as needed. If you hear distortion, turn down the device's volume control.

Wall Mounting the DSB-150

The DSB-150 can be wall mounted using the keyhole openings on the back of the system. Install two M5 or equivalent screws in the wall. They must be exactly $3^{15}/_{16}$" (100mm) apart, and level with each other. Leave about $^{3}/_{16}$" (5mm) of the screw shaft exposed so the head of the screw can engage the keyhole opening. Carefully position the DSB-150 keyhole openings over the screw head and set it in place. Be sure the cabinet is firmly mounted on the screw heads before you let go of the system.



Register your product online @ www.denon.com

www.denon.com

Denon is registered trademark of D&M Holdings Inc.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by D&M Holdings Inc. is under license. Other trademarks and trade names are those of their respective owners.
© 2013 CSR plc and its group companies.
The aptX® mark and the aptX logo are trade marks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.
The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.

5411 11203 00AD
Printed in China

Remove contents of box.



Quick Start Guide

Owner's Manual



AC power supply



Remote Control



DSB-150 speaker

1 Locate the DSB-150 near an AC power source and connect.



Press the ⏻ button.

2 Enable *Bluetooth*® on your mobile device.

If necessary, refer to the owner's manual of your mobile device.



3a Pair your mobile device to the DSB-150. Press and hold the ᛒ button for three seconds to launch the pairing process (button flashes rapidly).

Select "DSB-150" on the *Bluetooth* screen of your mobile device.

When the ᛒ button stops flashing, your mobile device is connected and you can begin streaming audio.



OR,

3b If you have an NFC enabled device, simply place it gently on the top of the DSB-150. Your phone or tablet does the rest, and you can be playing audio within seconds.



PRODUCT INFORMATION

DSB-150

TABLETOP BLUETOOTH® WIRELESS SPEAKER

DENON®

TABLETOP BLUETOOTH® SPEAKER WITH PREMIUM DENON SOUND

The DSB-150 is a Bluetooth® wireless speaker system that allows you to enjoy room-filling sound in your home or office directly from your phone, tablet, or PC without the need for a network connection. With its sleek, minimalist design, the system integrates easily with any decor. Simply place the DSB-150 on a counter, desk, or table, plug it in, pair your Bluetooth device, and enjoy a world of music as the DSB-150 fills the space with clear, full sound.

The DSB-150 includes near-field communication (NFC) for simple, tap-to-pair connectivity. This means users can literally tap a NFC-enabled device to the DSB-150 speaker for one-touch pairing. (Many of today's new phones and tablets include NFC.) The DSB-150 also features aptX® technology for CD-like sound quality over Bluetooth.

Bluetooth Wireless Connection for Convenient Streaming
The DSB-150 speaker system features Bluetooth which allows you to stream your favorite music wirelessly from a compatible device such as a smartphone, tablet, or PC. This technology conveniently eliminates the need for any wired connections, making set up easy. For devices that do not have Bluetooth capability, the DSB-150 includes an auxiliary analog input and headphone output.

One-Touch, Tap-to-Pair Connectivity
The unit is equipped with NFC (Near Field Communication) for simple tap-to-pair connectivity from mobile devices that are NFC equipped. Simply place your NFC-enabled mobile device, such as a smartphone, near the top of the DSB-150 to initiate pairing.

aptX Delivers CD-Quality Music
The DSB-150 also features aptX which allows for CD-quality sound when streaming from a Bluetooth device that also includes aptX. The audio quality from aptX is indistinguishable from wired music, matching CD performance for a top-quality listening experience.

Full System Sound
Thanks to dual designed, high-performance 3.5-inch drivers, the DSB-150 plays full-system sound from a compact speaker. The DSB-150 Bluetooth speaker plays your music with a wide range and very natural sound reproduction - so you can enjoy music as the artist intended (and not rely on the tiny speakers found in a mobile phone, tablet, or computer). Chances are, you'll hear notes and instruments you hadn't noticed before. The DSB-150 also features BassTrac circuitry for consistent, superior sound. BassTrac is a patented technology that controls bass output dynamically dependent on volume level for satisfying bass at any listening level.

Timeless Design Complements Home or Office
High-grade materials both inside and outside the speaker add to the simple style. The buttons are discreetly located on the top, conveniently positioned for intuitive use. A seamless base positions the speaker so it leans back slightly to create an elegant look. The clean, minimalist design of the DSB-150 blends easily into its surroundings and is perfectly suited for the home or office setting. The only color you will see is a blue LED volume indicator behind the grille, which lights only when the volume is changing.

KEY FEATURES

- **Bluetooth:** Wirelessly stream audio with Bluetooth enabled devices
  aptX: CD-quality wireless music streaming from aptX equipped devices
- **NFC:** Tap-to-pair for simple one touch pairing with NFC enabled devices
- **Performance:** Denon Sound with two 3.5-inch full-range drivers
- Remote control included
- AUX Input and headphone jack

Features

Analogue input (3.5mm mini jack)	•
Control buttons	•
NFC	•
aptX	•
Bluetooth	•

Bluetooth

Compatible Profiles	A2DP/AVRCP
Supported Codecs	aptX low latency/AAC/SBC
NFC bluetooth pairing	•

Specifications

Frequency Range	70Hz – 20kHz
System Speakers	Dual-3 1/2" (89mm) full range woofers

General

Available color: Black	•
Dimensions (W x H x D)	6 x 15 3/4 x 5 1/4" (152 x 400 x 134mm)
Weight	4.5 lb (2.04kg)
Available accessories	Remote Control Included

UPC

NA	8-83795-00335-3

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by D&M Holdings Inc. is under license. Other trademarks and trade names are those of their respective owners.
© 2013 CSR plc and its group companies.

The aptX® mark and the aptX logo are trade marks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.
The N MARK is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.
Copyright 2014 D&M Holdings Inc.

Denon is a trademark or registered trademark of D&M Holdings, Inc.

* All specs can be subject to change

Denon Electronics (USA), LLC.
100 Corporate Drive, Mahwah, New Jersey
07430 USA
TEL: 201-762-6500
usa.denon.com

DENON

Extended Protection Plan

It's Important to Protect Your Investment.

To start your Extended Protection Plan coverage:

1. Call us toll-free at **(855) 720-0823** (US Residents Only)
   Have your model number, serial number,
   and purchase receipt available when calling.

2. Log on to http://servicecontracts.denon.com

Copyright © 2011 D&M Holdings Inc. All Rights Reserved.

The Denon Extended Protection Plan

Today's highly technical products are mechanically and electronically complex, and even the best equipment may need periodic attention that can result in costly repair bills. With the Denon Extended Protection Plan, there are no deductibles or hidden charges. Best of all, if your Denon product is unrepairable, we will replace it, absolutely free with a unit that has similar features and functionality.

Don't delay! You must extend your coverage before your factory warranty expires. To extend your warranty, simply log on to our website: http://servicecontracts.denon.com, or call us toll-free at (855) 720-0823.

(US Residents Only)

Features & Benefits

- 100% coverage on parts & labor
- If unrepairable, we'll replace it!
- No deductibles or hidden charges
- Power surge protection
- Unlimited service calls
- Nationwide authorized service center network
- Service representatives available to assist you 24 hours a day
- *No Lemon* guarantee
- Fully insured
- Fully transferable

DENON

Congratulations on purchasing this Denon product!
We invite you to join the Denon Owner's Club.

Thank you for choosing Denon.
Be the first to know about upcoming Denon products and get exclusive previews of new technologies. You will also receive members only offers from our online store and be the first in line for all promotions and contests.
http://usa.denon.com/us/MyAccount/Pages/Login.aspx

Join today!

Please register your product at,

USA Customers : http://usa.denon.com/us/Support/Pages/ProductRegistration.aspx
Canada Customers : http://ca.denon.com/CA/Support/Pages/ProductRegistration.aspx

Denon Factory Service Information

USA

DENON FACTORY SERVICE by PANURGY OEM
701 Ford Road (South Dock)
Rockaway, NJ 07866-2053
(973) 625-4056
(973) 625-9489 Fax
http://www.panurgyoem.com/Denon/Denonrepair.html

To locate an authorized warranty service center within your area please visit our web site at
http://usa.denon.com/us/Support/Pages/ServiceCenterSearch.aspx

CANADA

DENON FACTORY SERVICE by MICROLAND TECHNICAL SERVICES
170 Alden Road, Unit 2
Markham, ON L3R4C1
(905) 940-1982
http://clientportal.microland.ca/rmastart.aspx

To locate an authorized warranty service center within your area please visit our web site at
http://ca.denon.com/CA/Support/Pages/ServiceCenterSearch.aspx

WARRANTY DE COMMON
5431 10003 60AD

This warranty will be honored only in the **U.S.A.**

DENON®

LIMITED WARRANTY

Length of Non-Transferable Warranty

This warranty on your DENON product which is distributed and warranted by DENON ELECTRONICS (USA), LLC remains in effect for the following periods from the date of the original consumer purchase from an AUTHORIZED DENON ELECTRONICS (USA), LLC DEALER.

Product Category					
A/V Controller, A/V Receiver, AM/FM Receiver			AVC, AVR, DRA	2	YEAR(S)
IN-Command series ™ AV Receivers, Sound bar			AVR-****CI, AVR-X****, DHT-S****	3	
DVD Receiver, DVD Home Theater System			ADV, S	1	
D/A Converter			DA	2	
Pre-Amplifier, Digital Pre-Amplifier, Power-Amplifier, Head Amplifier			PRA, AVP, DAP, POA, HA	3	
Tuner, Integrated Amplifier			TU, PMA	3	
Option Board			ACD	3	
CD Player, DVD Player, Blu-ray Disc Player			DCD, DCM, DVD, DVM, DBP, DBT	1	
CD Recorder			CDRW	1	
CD Receiver, Network CD Receiver, Network Receiver			RCD, DRA-N	1	
Network Audio Player			DNP	2	
System Audio			D-F, D-M, S	1	
Turntable	1	Autolift / Manual	DP-L, DP-M	4	
	2	Full Automatic	DP-F, DP-USB	2	
Speaker			SC	5	
Sub-woofer			DSW	1	
Microphone			DM-S, DM-A	2	
Bluetooth Speaker			DSB	1	
iPhone® / iPod® Docks			ASD, DSD	1	
Headphone			AH	1	
Front Surround Home Theater System			DHT-FS	1	
Video Processor			DVP	3	
Cartridge			DL	90	DAYS
Remote Controller			RC	90	
Cables			AK	90	
Speaker stands			ASF	90	

iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

What is Covered

Except as specified below, this Warranty covers all defects in material and workmanship in this product occurring during the above warranty periods. The following are not covered by the Warranty: (1) Any product which is not distributed in the U.S.A. by DENON ELECTRONICS (USA), LLC. (2) Any product which is not purchased in the U.S.A. from an authorized DENON dealer. (Note: AUTHORIZED DENON DEALERS can be identified by DENON AUTHORIZED DEALER sticker displayed in the stores. If you are uncertain as to whether a dealer is a DENON AUTHORIZED DEALER, please contact DENON as listed below). (3) Any product on which the serial number has been defaced, modified or removed. (4) Damaged deterioration or malfunction resulting from: a) Accident, act of nature, abuse, misuse, neglect, unauthorized product repair, opening of or modification or failure to follow instructions supplied with the product. b) Repair or attempted repair by anyone not authorized by DENON. c) Any shipment of the product (claim must be presented to carrier). (5) Items subject to wear from normal usage (tape heads, cartridges, stylus, battery, etc.). (6) Periodic check-ups which do not disclose any defect. (7) Use of the product outside the U.S.A. (8) Damaged magnetic tape or CD/DVD/BD discs. (9) Use in industrial, commercial, and/or professional applications. (10) Any installation or removal charges resulting from product failure.

What We Will Pay For

If during the applicable warranty period from the date of original consumer purchase your DENON product is found to be defective by DENON, DENON will repair, or at its option, replace with new, reconditioned or equivalent model, such defective product without charge for parts or labor.

How to Obtain Warranty Performance

If your unit ever needs service, it may be taken or shipped to any authorized DENON service station or DENON ELECTRONICS (if you are uncertain as to whether a service station is DENON authorized, please visit our website at http://usa.denon.com/us/Support/Pages/ServiceCenterSearch.aspx or contact DENON as listed below.) In all other cases, the following procedures apply whenever your unit must be transported for warranty service;

a. You are responsible for transporting your unit or arranging for its transportation.
b. If shipment of your unit is required;
   You must pay the initial shipping charges, but we will pay the return shipping charges if the repairs are covered by the Warranty.
c. WHEN RETURNING YOUR UNIT FOR WARRANTY SERVICE, A COPY OF THE ORIGINAL SALES SLIP MUST BE ATTACHED.
d. You should include the following: your name, address, daytime telephone number, model and serial number of the product and a description of the problem.
   In the case of a CD/DVD/BD Player, please enclose ONE (1) disc that the unit has failed with for test reasons. It will be returned with the unit.

THIS WARRANTY IS VALID IN THE U.S.A. ONLY.

If your product does not require service, but you have questions regarding its operation, please contact our Customer Support Department as listed below.

THIS WARRANTY IS EXPRESSLY MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

OUR LIABILITY IS LIMITED TO THE REPAIR OR REPLACEMENT, AT OUR OPTION, OF ANY DEFECTIVE PRODUCT AND SHALL IN NO EVENT INCLUDE INCIDENTAL OR CONSEQUENTIAL COMMERCIAL OR PROPERTY DAMAGES OF ANY KIND. WE ARE NOT RESPONSIBLE FOR PRODUCTS LOST, STOLEN AND/OR DAMAGED DURING SHIPPING.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS AND/OR DO NOT ALLOW THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights, but you may also have other rights which vary from state to state. This Warranty may not be altered other than in a writing signed by an officer of Denon Electronics USA, LLC.

DENON ELECTRONICS (USA), LLC
(a D&M Holdings Company)
100 Corporate Drive
Mahwah, NJ 07430-2041
(201) 762-6665
www.usa.denon.com

DENON FACTORY SERVICE by PANURGY OEM
701 Ford Road (South Dock)
Rockaway, NJ 07866-2053
(973) 625-4056
(973) 625-9489 Fax
http://www.panurgyoem.com/Denon/Denonrepair.html

This warranty will be honored only in **Canada.**

DENON®

LIMITED WARRANTY

Length of Non-Transferable Warranty

This warranty on your DENON product which is distributed and warranted by D&M CANADA INC. remains in effect for the following periods from the date of the original consumer purchase from an AUTHORIZED D&M CANADA INC. DEALER.

Product Category					
A/V Controller, A/V Receiver, AM/FM Receiver			AVC, AVR, DRA	2	YEAR(S)
IN-Command series ™ AV Receivers, Sound bar			AVR-****CI, AVR-X****, DHT-S****	3	
DVD Receiver, DVD Home Theater System			ADV, S	1	
D/A Converter			DA	2	
Pre-Amplifier, Digital Pre-Amplifier, Power-Amplifier, Head Amplifier			PRA, AVP, DAP, POA, HA	3	
Tuner, Integrated Amplifier			TU, PMA	3	
Option Board			ACD	3	
CD Player, DVD Player, Blu-ray Disc Player			DCD, DCM, DVD, DVM, DBP, DBT	1	
CD Recorder			CDRW	1	
CD Receiver, Network CD Receiver, Network Receiver			RCD, DRA-N	1	
Network Audio Player			DNP	2	
System Audio			D-F, D-M, S	1	
Turntable	1	Autolift / Manual	DP-L, DP-M	4	
	2	Full Automatic	DP-F, DP-USB	2	
Speaker			SC	5	
Sub-woofer			DSW	1	
Microphone			DM-S, DM-A	2	
Bluetooth Speaker			DSB	1	
iPhone® / iPod® Docks			ASD, DSD	1	
Headphone			AH	1	
Front Surround Home Theater System			DHT-FS	1	
Video Processor			DVP	3	
Cartridge			DL	90	DAYS
Remote Controller			RC	90	
Cables			AK	90	
Speaker stands			ASF	90	

iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

What is Covered

Except as specified below, this Warranty covers all defects in material and workmanship in this product occurring during the above warranty periods. The following are not covered by the Warranty: (1) Any product which is not distributed in Canada by D&M CANADA INC. (2) Any product which is not purchased in Canada from an authorized DENON dealer. (Note: AUTHORIZED DENON DEALERS can be identified by DENON AUTHORIZED DEALER sticker displayed in the stores. If you are uncertain as to whether a dealer is a DENON AUTHORIZED DEALER, please contact D&M CANADA INC. as listed below). (3) Any product on which the serial number has been defaced, modified or removed. (4) Damaged deterioration or malfunction resulting from: a) Accident, act of nature, abuse, misuse, neglect, unauthorized product repair, opening of or modification or failure to follow instructions supplied with the product. b) Repair or attempted repair by anyone not authorized by DENON. c) Any shipment of the product (claim must be presented to carrier). (5) Items subject to wear from normal usage (tape heads, cartridges, stylus, battery, etc.). (6) Periodic check-ups which do not disclose any defect. (7) Use of the product outside Canada. (8) Damaged magnetic tape or CD/DVD/BD discs. (9) Use in industrial, commercial, and/or professional applications. (10) Any installation or removal charges resulting from product failure.

What We Will Pay For

If during the applicable warranty period from the date of original consumer purchase your DENON product is found to be defective by DENON, DENON will repair, or at its option, replace with new, reconditioned or equivalent model, such defective product without charge for parts or labor.

How to Obtain Warranty Performance

If your unit ever needs service, it may be taken or shipped to any authorized DENON service station or D&M CANADA INC. (For an authorized DENON service station near you, please check our website http://ca.denon.com/CA/Support/Pages/ServiceCenterSearch.aspx or contact D&M CANADA INC. as listed below.) In all other cases, the following procedures apply whenever your unit must be transported for warranty service;

a. You are responsible for transporting your unit or arranging for its transportation.
b. If shipment of your unit is required;
   You must pay the initial shipping charges, but we will pay the return shipping charges if the repairs are covered by the Warranty.
c. WHEN RETURNING YOUR UNIT FOR WARRANTY SERVICE, A COPY OF THE ORIGINAL SALES SLIP MUST BE ATTACHED.
d. You should include the following: your name, address, daytime telephone number, model and serial number of the product and a description of the problem.
   In the case of a CD/DVD/BD Player, please enclose ONE (1) disc that the unit has failed with for test reasons. It will be returned with the unit.

THIS WARRANTY IS VALID IN CANADA ONLY.

If your product does not require service, but you have questions regarding its operation, please contact our Customer Support Department as listed below.

THIS WARRANTY IS EXPRESSLY MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

OUR LIABILITY IS LIMITED TO THE REPAIR OR REPLACEMENT, AT OUR OPTION, OF ANY DEFECTIVE PRODUCT AND SHALL IN NO EVENT INCLUDE INCIDENTAL OR CONSEQUENTIAL COMMERCIAL OR PROPERTY DAMAGES OF ANY KIND. WE ARE NOT RESPONSIBLE FOR PRODUCTS LOST, STOLEN AND/OR DAMAGED DURING SHIPPING.

SOME PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS AND/OR DO NOT ALLOW THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights, but you may also have other rights which vary from province to province. This Warranty may not be altered other than in a writing signed by an officer of D&M Canada Inc.

D&M CANADA INC.
10462 Islington Avenue, Unit 8B
Kleinburg, Ontario L0J 1C0
(905) 475-4085
www.ca.denon.com

DENON FACTORY SERVICE
by MICROLAND TECHNICAL SERVICES
170 Alden Road, Unit 2
Markham, ON L3R 4C1
(905) 940-1982
http://clientportal.microland.ca/rmastart.aspx

Cette garantie ne sera honorée qu'au **Canada.**

DENON®

GARANTIE LIMITÉE

Durée du garantie non-transférable

La garantie de votre produit DENON, distribué et garanti par D&M CANADA INC. prend effet à partir de la date d'achat du consommateur original auprès d'un revendeur official D&M CANADA INC. pendant les périodes suivantes.

Catégorie de produit

Contrôleur A/V, Récepteu A/V, Récepteur AM/FM			AVC, AVR, DRA	2	ANNÉES
IN-Command series ™ Récepteurs AV, Barre de son			AVR-****CI, AVR-X****, DHT-S****	3	
Récepteur DVD, Système DVD Home Theater			ADV, S	1	
Convertisseur N/A			DA	2	
Préamplificateur, préamplificateur numérique, Amplificateur de puissance, Préamplificateur phono			PRA, AVP, DAP, POA, HA	3	
Syntoniseur, amplificateur intégré			TU, PMA	3	
Carte optionnelle			ACD	3	
Lecteur CD, Lecteur DVD, Lecteur Disque Blu-ray			DCD, DCM, DVD, DVM, DBP, DBT	1	
Enregistreur CD			CDRW	1	
Ampri-tuner avec Lecteur de CD, Récepteur audio / CD avec réseau intégré / Chaine audio avec réseau intégré			RCD, DRA-N	1	
Lecteur Audio Réseau			DNP	2	
Système Audio			D-F, D-M, S	1	
Table tournante	1	Levée auto	DP-L, DP-M	4	
	2	Auto complet	DP-F, DP-USB	2	
Haut-parleurs			SC	5	
Sub-woofer			DSW	1	
Micro			DM-S, DM-A	2	
Enceinte Bluetooth			DSB	1	
iPhone® / iPod® Docks			ASD, DSD	1	
Casque d'écoute			AH	1	
Avant Surround Système Home Theater			DHT-FS	1	
Processeur vidéo			DVP	3	
Cellule phonolectrice			DL	90	JOURS
Télécommande			RC	90	
Câble			AK	90	
Support pour enceinte acoustique			ASF	90	

Apple et iPod sont des marques commerciales d'Apple Inc., déposées aux Etats-Unis et dans d'autres pays.

Couverture

Cette garantie couvre tous les défauts de matériel ou de fabrication du produit, à l'exception de ceux indiqués ci-après qui conforrment selon les termes durant la periode de la garantie. Ne sont pas couverts par la garantie: (1) Tout produit qui n'est pas distribué au Canada par D&M CANADA INC. (2) Tout produit qui n'a pas été acheté au Canada auprès d'un revendeur officiel DENON (Note: On peut identifier les revendeurs officiels DENON par leur auto-collant "REVENDEUR OFFICIEL DENON" affiché dans leur magasin. Si vous doutez qu'un revendeur soit officiellement reconnu, contactez D&M CANADA INC. à l'adresse ci-dessous.) (3) Tout produit dont le numéro de série a été effacé, modifié ou enlevé. (4) Dommages dus à la détérioration ou à un fonctionnement défectueux à la suite de: a) accident, acte de la nature, abus, utilisation impropre, négligence, réparation au moyen d'un produit non autorisé, debalé, modification, emploi contraire aux instructions fournies avec le produit, b) réparation ou tentative de réparation par quelqu'un non reconnu par DENON. c) tout envoi du produit (la réclamation doit être présentée au transporteur), (5) Articles sujets à détérioration par l'usage (têtes de magnétophone, cellules phono, pointes de lecture phono, piles, etc.). (6) Vérification périodique qui ne révèle aucun défaut. (7) Utilisation du produit hors du Canada. (8) Bandes magnétiques, disques CD/DVD/BD endommagés. (9) Utilisation commerciale, industrielle ou professionnelle. (10) Toutes charges d'installation ou de déplacement résultant d'un défaut du produit.

Notre paiement

Si votre produit DENON est reconnu défectueux par DENON durant la période d'application de la garantie après la date d'achat du consommateur, DENON réparera ou, à son choix, remplacera avec un modèle neuf, usagé ou équivalent ce produit défectueux sans frais de pièces ni de main d'œuvre.

Application de la garantie

Si votre appareil nécessite une vérification ou une réparation, il peut être apporté ou envoyé à tout atelier de service autorisé DENON ou directement chez D&M CANADA INC. (Pour trouver l'atelier autorisé le plus près, prière de vérifier sur le site Internet de DENON au http://ca.denon.com/CA/Support/Pages/ServiceCenterSearch.aspx ou bien contactez D&M Canada Inc aux coordonnés indiquées ci bas).
Dans tous les autres cas, les procédures suivantes s'appliquent si votre appareil doit être envoyé pour une vérification ou une réparation sous garantie.

a. Vous êtes responsable du transport de votre article ou vous devez vous arranger vous-même pour son transport.
b. Si votre article doit être envoyé, vous devez payer les frais d'envoi initiaux, mais nous payerons les frais de retour si la garantie couvre les réparations.
c. LORSQUE VOUS RENVOYEZ VOTRE ARTICLE POUR UN SERVICE SOUS GARANTIE, VOUS DEVEZ JOINDRE UNE COPIE DE LA FACTURE D'ACHAT D'ORIGINE.
d. Vous devez inclure également vos nom, adresse, numéro de téléphone de jour, numéros de modèle et de série du produit et une description du problème. Dans le cas d'un lecteur CD/DVD/BD, joindre un disque que l'appareil n'a pu lire pour test. Il vous sera retourné avec l'article.

CETTE GARANTIE EST VALABLE SEULMENT AU CANADA.

Si votre produit ne requiert aucun service mais que vous avez des questions quant à son fonctionnement, contactez notre département service clientèle dont l'adresse figure ci-dessous.

CETTE GARANTIE EST EXPRESSÉMENT FAITE EN LIEU ET PLACE DE TOUTES LES AUTRES GARANTIES EXPRIMÉES OU SOUS-ENTENDUES' Y COMPRIS, SANS SE LIMITER À CELLES-CI, LES GARANTIES MARCHANDES ET SPÉCIFIQUES POUR UN USAGE PARTICULIER.

NOTRE RESPONSABILITÉ SE LIMITE À LA RÉPARATION OU AU REMPLACEMENT, À NOTRE CHOIX, DE TOUT PRODUIT DÉFECTUEUX ET N'INCLUT EN AUCUN CAS DES DOMMAGES FORTUITS, COMMERCIAUX INDIRECTS NI MATÉRIELS D'AUCUNE SORTE. NOUS NOUS SOMMES PAS RESPONSABLES POUR LA PERTE DE LES PRODUITS ET/OU LES MARCHANDISES ENDOMMAGEES PENDANT LE TRNASPORT DES BIENS.

CERTAINES PROVINCES NE PERMETTENT PAS DE LIMITES QUANT À LA DURÉE D'UNE GARANTIE SOUS-ENTENDUE ET/OU NE PERMETTENT PAS L'EXCLUSION DE DOMMAGES FORTUITS. LES LIMITATIONS ET EXCLUSIONS MENTIONNÉES PLUS HAUT PEUVENT NE PAS S'APPLIQUER À VOTRE CAS.

Cette garantie vous donne des droits légaux spécifiques, mais il se pourrait que vous ayez d'autres droits qui varient d'une province à l'autre. La garantie ne peut être modifiée que par un document signé par un gestionnaire autorisé de D&M Canada.

D&M CANADA INC.
10462 Islington Avenue, Unit 8B
Kleinburg, Ontario L0J 1C0
(905) 475-4085
www.ca.denon.com

DENON FACTORY SERVICE
by MICROLAND TECHNICAL SERVICES
170 Alden Road, Unit 2
Markham, ON L3R 4C1
(905) 940-1982
http://clientportal.microland.ca/rmastart.aspx